STAND 2

Assembly Instruction



REVIVAL AUDIO

1



*6

*1



*3

REVIVAL AUDIO

2



*6

*1

*4

*3

REVIVAL AUDIO

3



*4

REVIVAL AUDIO